



INSTALLATION INSTRUCTIONS




Diagram 1—Excavation




Diagram 2—Leveling Pad




Diagram 3—Base Course




Diagram 4—Core Fill

1 STAKE OUT THE WALL

- Have a surveyor stake out the wall's placement. Verify the locations with the project supervisor.

2 EXCAVATION

- Excavate for the leveling pad to the lines and grades shown on the approved plans, and excavate enough soil from behind the wall for the geosynthetic reinforcement material.
- The trench for the leveling pad should be at least 2 feet wide and a minimum of 1 foot 2 inches deep, enough to bury the first course below grade, plus 6 inches for the leveling pad. Ensure that a minimum of 8 inches or 10 percent of the total wall height (whichever is greater) is below grade. *See Diagram 1.*

3 LEVELING PAD

- An aggregate leveling pad is made of compactible base material of $\frac{3}{4}$ -inch minus with fines.
- If the planned grade along the wall front will change elevation, the leveling pad may be stepped up by the height of the block (typically 8-inch increments) to match the grade change. Always start at the lowest level and work upward.
- Compact the aggregate, making sure it's level front to back and side to side. Mist lightly with water before compaction, if needed. *See Diagram 2.*

4 BASE COURSE

- This is the most important step in the installation process.
- Begin laying block at the lowest elevation of the wall, whenever possible. Remove the rear lip of the block by hitting with a hammer and chisel from the back so that the block will lie flat on the leveling pad.
- Place first block and level, front to back and side to side; lay subsequent blocks in same manner.
- Place the blocks side by side, flush against each other, and make sure the blocks are in full contact with the leveling pad. Level front to back and side to side.
- Place soil in front of the base course and compact. Base course should be buried. Continue to fill and compact after each course is laid.

- If the wall is on an incline, don't slope the blocks. Step them up so they remain consistently level.
- Use string along back edge of the block to check for proper alignment. *See Diagram 3.*

5 CONSTRUCTION OF THE NEXT COURSE

- Fill cores and voids between blocks with $\frac{3}{4}$ -inch clean drainage aggregate prior to laying the next course of block. Clean any debris off the top of the blocks.
- Place the second course of blocks on top of the base course. Maintain running bond. Pull each block forward as far as possible to ensure the correct setback.
- Backfill with drainage aggregate directly behind the block, adding 6 to 8 inches at a time. Add soil fill behind the aggregate.
- Compact before the next course is laid. Don't drive heavy equipment near the wall. Self-propelled compaction equipment should not be used within 3 feet of the back of the wall.
- You'll need partial units to stay on bond. A circular saw with a masonry blade is recommended for cutting partial units. Use safety glasses and other protective equipment when cutting. *See Diagrams 4 and 5.*

6 DRAINAGE DESIGN

- Each project is unique. The grades on the site will determine at what level to install the drainpipe. Place the drainpipe (4-inch perforated piping) so water drains down and away from the wall into a storm drain, or daylight just above grade.
- Fill in the area behind the blocks with clean drainage aggregate, at least 1 foot from the wall. You may need to place and backfill several courses to achieve the proper drainage level.
- The outlet pipes should be spaced not more than every 50 feet and at low points of the wall. In order for the drainage aggregate to function properly, it must keep clear of regular soil fill. *See Diagrams 6 and 7.*

INSTALLATION INSTRUCTIONS




Diagram 5—Next-Course Construction




Diagram 6—Drainage




Diagram 7—Backfill




Diagram 8—Compaction

7 COMPACTION

- Shovel the backfill soil behind the drainage aggregate and compact the backfill with a hand-operated compactor. Make sure the aggregate is level with or slightly below the top of the base course.
- Continue to fill and compact after each course is laid. See *Diagrams 7 and 8*.

8 REINFORCEMENT (IF REQUIRED)

- Geosynthetic reinforcement is recommended for walls taller than 4 feet or walls situated in poor soils, supporting a driveway, etc. Consult an engineer for design assistance.
- Check the wall construction plan to determine which courses will need reinforcement. Clean any debris off the top layer of blocks. Measure and cut the reinforcement to the design length in the plans. The reinforcement has a design strength direction, which must be laid perpendicular to the wall.
- Place the front edge of the material on the top course, 1 inch from the face of the block.
- Apply the next course of blocks to secure it in place. To keep it from wrinkling, pull the reinforcement taut and pin the back edge in place with stakes or staples.
- Add drainage aggregate behind the blocks; then add the backfill soil and compact it.
- Correct placement ensures that you maximize the connection strength and keep the batter consistent. A minimum of 6 inches of backfill is required prior to operating vehicles on the reinforcement.

9 CAPPING A WALL

- Always start capping from the lowest elevation. If the wall elevation changes, caps can be stacked where the wall steps up.
- Lay caps at the elevation change and work back toward the previous step up. Cut caps with a diamond-blade saw to fit, as needed.

- Carefully glue with a high-strength concrete adhesive.

10 FINISH GRADE AND SURFACE DRAINAGE

- Protect the wall with a finished grade at the top and bottom. To ensure proper water drainage away from the wall, use 6 inches of soil with low permeability and seed or plant to stabilize the surface.
- Consult the wall design engineer if water may be directed behind the wall. If needed, create a swale to divert water away from the wall. This will minimize water seeping into the soil and drainage aggregate behind the wall.

11 SITE CLEANING AND RESTORATION

- Brush off the wall and pick up any debris left from the construction process. Notify the job superintendent in writing of the completion and that it is ready for final inspection and acceptance.
- Planting vegetation in front and on top of the wall will help reduce the chance of erosion.
- Following these best practices for construction will ensure the success of your Anchor Wall Systems retaining wall. These instructions are meant as general guidelines. Site-specific conditions may warrant additional installation requirements.
- Anchor Wall Systems recommends you consult a professional engineer to design walls over 4 feet high, and have compaction tested by a qualified geotechnical engineer.

SAFETY NOTE: Always use appropriate equipment, including safety glasses or goggles and respirators, when splitting, cutting or hammering units.



LOCATIONS & CONTACT INFO

ASP ENTERPRISES

aspent.com
salesasp@aspent.com

BOWMAN CONSTRUCTION SUPPLY

bowmanconstructionsupply.com
salesbcs@bowmanconstructionsupply.com

QUICK SUPPLY CO.

quicksupplyco.com
salesquick@quicksupplyco.com

CASCADE GEOSYNTHETICS

cascadegeos.com
salescascade@cascadegeos.com

St. Louis, MO 636.343.4357
Omaha, NE 402.861.8579

Kansas City, MO 816.554.1191
Wichita, KS 316.393.1554

Denver, CO 303.696.8960
Colorado Springs, CO 719.257.7840

Loveland, CO 970.535.0863

Des Moines, IA 515.289.1271

Portland, OR 971.339.1020

SOLUTIONS WE SUPPLY

GEOSYNTHETICS

Filter Fabrics
Stabilization Fabrics

Geogrids

- Road Grids
- Wall Grids
- Slope Stabilization

Specialty Fabrics

Composite Geomembranes

- GCLs, PVC, HDPE, LLDPE, EPDM, Granular Bentonite

SEDIMENT CONTROL

Inlet Protection

- Grated Inlet, Curb Inlet, Area Inlet Protection

Ditch Checks

- Triangle Silt Dike
- GeoRidge

Perimeter Protection

- High and Low-Porosity Silt Fence, Straw Wattles, Silt Socks
- Safety Fence

Flocculants & Water Treatment

- Polymer-Based & Natural Flocculants

Sediment Basin Skimmers

Dewatering Bags

Trackout Control

- FODS
- Rumble Grates

Turbidity Curtains

EROSION CONTROL

Basic Hydraulically Applied Mulches

- Wood
- Paper
- Blends
- Straw

High-Performance Hydraulically Applied Products

- BFM
- FGM
- Additives & Tackifiers

Temporary Erosion Control Blankets

- Coir & Jute Mat/Nettings
- Short-Term ECBs
- Extended-Term ECBs

Permanent Erosion Control Blankets

- Turf Reinforcement Mats
- HP-TRMs
- Anchor Reinforced Vegetation System

Structural BMPs

- Transition Mats
- Geoweb Cellular Confinement
- Composite Vegetated Armor System
- Flex MSE Vegetated Wall System
- Articulated Concrete Block
- Gabions
- Grout-Filled Geotextile Mats

Vegetation Establishment

- Native Seed & Turf Seed
- Fertilizers
- Organic Soil Additives
- Stratavault Soil Cells

STORMWATER MANAGEMENT

Water Quality

- Inlet Filter Boxes
- Pre-Treatment Chamber
- Nutrient Separating Baffle Boxes
- High-Flow Biofiltration Media
- Hydrodynamic Separators
- Stratavault

Water Quantity

- Modular Underground Storage Systems
- Chamber Detention Systems

Drainage

- HDPE Swale Liner
- Pipe & Fittings
- Drainage Composites
- Strip Drain

Inlet Structures

- PVC
- Drain Basins, In-Line Drains
- Landscape

Permeable Pavers

- Permeable Articulating Concrete Block
- Grass Pavers
- Gravel Pavers
- Concrete Pavers

SPECIALTY

Natural & Synthetic Coir Fiber Logs

Vegetated Reinforced Soil Slopes

Soil Anchors

Root Barrier System

AquaBlok

Muscle Wall

We are full line distributors of construction materials for all project types. Contact us for assistance with a project. From specification and development to installation and completion, we're here to help with all of your site solution needs.

**GEOSYNTHETICS | EROSION CONTROL | STORMWATER MANAGEMENT
SEDIMENT CONTROL | REVEGETATION | HARDSCAPES**